

GL101L Intelligent Temperature Controller User's Guide



1 Caution

Abnormal operating conditions can lead to one or more undesirable events that, in turn, could lead to injury to personnel or damage to the equipment or other property. Do not touch the AC terminals while the power is supplied to the controller to prevent an electric shock. Make sure power is disconnected while checking the unit inside. To minimize the risk of potential safety problems, you should follow all applicable local and national codes that regulate the installation and operation of your equipment.

2 Features

- Compact size, only 24x48x75mm.
- RTD input (PT100, CU50) or Thermocouple input (T, R, J, B, S, K, E, WRe3-WRe25).
- Display the temperature in Celsius or Fahrenheit.
- Universal controller to work with either SSR or mechanical relay (contactor).
- Set control mode to PID or on/off, for either SSR or mechanical relay (contactor).
- When set the main control to SSR output, the internal relay J1 can be set for alarm.

3 Specifications

- Power supply: AC/DC85~260V (50Hz/60Hz).
- J1 relay contact capacity: AC250V/3A.
- Relay contact life: 1×10^5 .
- SSR control signal: 12V (open-circuit voltage), 30mA (short-circuit current).
- Temperature accuracy: 0.2%FS.
- Dimensions: 48x24x75mm.
- Mounting panel cutout: 45x22mm

4 Back terminals




Figure 1 Back Terminals Wiring Diagram

4.1 Sensor connection

The default setting for the input type is for K type thermocouple, for different probe type, the parameter **Int** in [Table 1](#) need to be changed.

For thermocouple, connect the positive wire to terminal 7 and the negative wire to terminal 6. For K type thermocouple, if the wires are red and yellow, the yellow wire is positive. If they are red and other color (blue, white, green...), the red is positive. If the polarity is reversed, when the temperature goes higher, the readout will decrease.

For three-wire PT100 probe, if the wire color code is red, red and white (to IEC60751), connect the two red wires to terminals 6 and 7 respectively, and connect the white wire to terminal 8. For two-wire PT100 probe, connect one wire to terminal 7 and connect the other wire to terminal 8, and short the terminals 6 and 7. The parameter **Int** need to be changed to Pt, which has 1 degree display resolution.

4.2 SSR connection

When the main control output is set to SSR (**OUT** in [Table 1](#) is set to 2 or 3), the SSR output is enabled. The terminal 10 should be connected to the positive pole of the DC control side of the SSR, the terminal 9 should go to the negative pole of the SSR. When there is no SSR connected to the terminals 9 and 10, there should be around 8V DC between them when the **OUT** indicator is on.

4.3 J1 relay connection

J1 relay can be set to PID or on/off control output, or can be used as an alarm relay (see **OUT** in [Table 1](#)). Please note the J1 relay is just a switch, there is no power on it. The power need to be provided to the load connected to the terminal 4 and 5.

4.4 Power to the controller

The controller can be powered by AC/DC from 85 to 260V. The ground power line is not necessary. For DC power, the polarity does not matter.

5 Front Panel




Figure 2 Front Panel

- 1 – SV, target temperature display
- 2 – Up key, select next parameter or increase value
- 3 – Down key, select previous parameter or decrease value
- 4 – Shift Key, Shift the digit when changing the setting, or press and hold the key to start [Auto tune](#).
- 5 – SET key, parameter set/confirm
- 6 – PV, Measured value (PV) display
- 7 – Temperature unit setting, °C or °F
- 8 – AL, relay J1 output display
- 9 – OUT, SSR control output display/auto tune display

6 Initial function parameters (input passcode 089 after pressing the SET key)

Table 1

Symbol	Name	Description	Range	Factory Value	Mark
<i>Int</i>	Int	Input type	See Table 2	K	Note 1
<i>out</i>	Out	Control output mode	0, 1, 2, 3, 4, 5	2	Note 2
<i>Hy</i>	Hy	Hysteresis Band	0~1999	3	Note 3
<i>PSb</i>	PSb	Display temperature offset	-199~1999 (degrees)	0	Note 4
<i>rd</i>	rd	Control action type	0: heat; 1: cool	0	
<i>Cor</i>	Cor	Display Unit selection	0: °C; 1: °F	1	
<i>End</i>	END	Exit			

To access the 089 menu, press and hold the **SET** key, the display will show 000, use the **UP/DOWN** key to change the value to 089. Press **SET** key, the display will change to be *Int*. Press **UP/DOWN** key to change the display to other parameters, or press **SET** key again to modify the value for *Int*, then press **SET** key to confirm the change. When changing the value, user can use the > key to shift the digit. Use the same operation to access the [SV and alarm parameters](#) (input passcode 001 after pressing the **SET** key) and [PID parameters](#) (input passcode 036 after pressing the **SET** key) menu.




Figure 3. Initial function parameters setup

Note 1. The default setting for the input probe type is K type thermocouple. If not, please change the **Int** to the one of the input type shown in [Table 2](#).

Table 2

Symbol	Name	Sensor Type	Temperature Range	Note
<i>t</i>	T	T type thermocouple	-200~400 °C; -320~752 °F	Internal resistance 100Kohms
<i>r</i>	R	R type thermocouple	-50~1600 °C; -58~1999 °F	
<i>J</i>	J	J type thermocouple	-200~1200 °C; -320~1999 °F	
<i>H r E</i>	WRE	Wre type thermocouple	0~1999 °C; 32~1999 °F	
<i>b</i>	B	B type thermocouple	350~1800 °C; 660~1999 °F	
<i>S</i>	S	S type thermocouple	-50~1600 °C; -58~1999 °F	
<i>P</i>	K	K type thermocouple	-200~1300 °C; -320~1999 °F	
<i>E</i>	E	E type thermocouple	-200~900 °C; -320~1650 °F	Constant current 0.2mA
<i>Pt</i>	Pt	PT100 RTD, 1° resolution	-199~600 °C; -99.9~999 °F	
<i>Cu</i>	Cu50	CU50 RTD	-200~600 °C; -320~1100 °F	

Note 2. Out - Control output mode

- 0: Set J1 relay as alarm output, SSR output disabled.
- 1: Set J1 relay as PID control output, SSR output disabled. SV is the control temperature.
- 2: Set J1 relay as alarm output, set SSR as PID control output. SV is the control temperature.

- 3: Set J1 relay as alarm output, set SSR as on/off control output. SV is the control temperature.
- 4: Set J1 relay as on/off control output, SSR output disabled.
- 5: Set J1 relay as deviation alarm output, set SSR as PID control output. SV is the control temperature.




Figure 4. Deviation Alarm

Note 3. Hy - Hysteresis Band

The parameter Hy is only for on/off control. For heating control mode, when the measured temperature PV reaches the target temperature **SV**, the control output will be off; when PV drops down to **SV-Hy**, the control output will be on again. For cooling control mode, when PV drops down to SV, the control output will be off, when PV increases to **SV+Hy**, the control output will be on again.




Figure 5. on/off control

Note 4. PSb - Display temperature offset

This feature allows the input value to be changed to agree with an external reference or to compensate for sensor error. For example, if the measured temperature of the controller is 100 degrees, but the reference temperature is 98 degrees. By setting the **PSb**= -2, the PV display of the controller would change to be 98. To set the negative value for **PSb**, use the > key to move the focus digit to the first digit from the left, then use the down key to change the digit to show the negative symbol.

7 PID parameters (input passcode 036 after pressing the SET key)

Table 3

Symbol	Name	Description	Range	Factory value	Mark
P	P	Proportional band	1~1999	50	Note 5
I	I	Integral time	0~1999 Seconds	100	Note 6

<i>d</i>	d	Derivative time	0~999 Seconds	20	Note 7
<i>Sou</i>	Sou	Overshoot suppression factor	0~10	2	Note 8
<i>ot</i>	ot	Proportional cycle	2~500 seconds	2	Note 9
<i>FLt</i>	FLt	Digital filter factor	0~3	0	Note 10
<i>End</i>	END	Exit			

Note 5. P – Proportional band

The proportional term produces an output value that is proportional to the current error value. A high proportional gain results in a large change in the output for a given change in the error. If the proportional gain is too high, the system can become unstable. In contrast, a small gain results in a small output response to a large input error, and a less responsive or less sensitive controller. If the proportional gain is too low, the control action may be too small when responding to system disturbances. In a real system, proportional-only control will leave an offset error in the final steady-state condition. Integral action is required to eliminate this error.

Note 6. I – Integral time

The contribution from the integral term is proportional to both the magnitude of the error and the duration of the error. The integral in a PID controller is the sum of the instantaneous error over time and gives the accumulated offset that should have been corrected previously. The accumulated error is then multiplied by the integral gain and added to the controller output. The integral term accelerates the movement of the process towards set point and eliminates the residual steady-state error that occurs with a pure proportional controller. However, since the integral term responds to accumulated errors from the past, it can cause the present value to overshoot the set point value.

Note 7. d – Derivation time

The derivative of the process error is calculated by determining the slope of the error over time and multiplying this rate of change by the derivative gain. The magnitude of the contribution of the derivative term to the overall control action is termed the derivative gain. Derivative action predicts system behavior and thus improves settling time and stability of the system. An ideal derivative is not causal, so that implementations of PID controllers include an additional low pass filtering for the derivative term, to limit the high frequency gain and noise. Normally *d* is set to 25% of the *I* value.

Note 8. Sou – Overshoot suppression factor

Overshooting and undershooting are restricted by the **Sou** and increase of the parameter can suppress the overshooting.

Note 9. ot – Proportional cycle

It's the cycle time to switch the output on/off. Within the cycle *t* time, the output will turn on and off once. For SSR, in general the cycle time is set to 2 seconds. For mechanical relays, set the cycle time to a higher value (for example, 5~60 seconds) to save the life time of the relay.

Note 10. Flt – digital filter factor

The filter is to increase the measured temperature display stability, but will delay the response. When **Flt** is set to 0, the filter is disabled. 1, 2 and 3 are weak, medium and strong, respectively.

8 Auto tune

For PID control mode, if the control with default **P**, **I** and **d** parameters settings are not able to hold the target temperature, the built-in auto tune function can find the right PID parameters for the system automatically. When on heating mode, it will heat up the system to the target temperature then let the system cool down. It will repeat this process for about 3 times, then the controller will calculate the parameters.

To activate the auto tune function, press and hold the **>** key until the "OUT" indicator starts to blink. When auto tune process finished, the "OUT" indicator will stop blinking. The new values for parameters **P**, **I** and **d** are calculated by the controller.

To stop the auto-tuning, press and hold **>** key for 3 seconds, until "OUT" indicator stops blinking. The PID parameters values will not change.

Please note:

- Auto tune from time to time, there could be a significant temperature overshoot, if so, please lower **SV** value to prevent accident.
- The sensor, load (heater...) need to be connected properly, otherwise, the auto tune will not complete.
- The time for the auto tune depends on the system response time, would be from a few minutes to hours.
- Only need to run auto tune one time.
- The controller uses the current PID settings as a baseline. Different initial PID settings will lead to different auto tune result. If the temperature control is not ideal such as the very slow to heat up, you may try to change the PID settings and run auto tune again to get a better result.

9 SV and alarm parameters (input passcode 001 after pressing the SET key)

Table 4.

Symbol	Name	Description	Factory value	Mark
<i>S_v</i>	SV	Target temperature (Set Value)	80	Note 11
<i>AH1</i>	AH1	Alarm (J1 relay) on temperature	800	Note 12
<i>AL1</i>	AL1	Alarm (J1 relay) off temperature	900	
<i>End</i>	END	Exit		

Note 11. The SV value can be set by accessing the 001 menu. Or, when in normal operation mode, use the **UP** or **DOWN** key to change the **SV** directly.

Note 12. When the J1 relay is set as alarm, the relay will be controlled by the two parameters **AH1** and **AL1**. The alarm can be set as either high limit alarm or low limit alarm.

For high alarm, set **AH1**>**AL1**. When the temperature increase to **AH1**, the J1 relay will be closed (alarm on), when the temperature drops down to **AL1**, the J1 relay will be open (alarm off).

For low alarm, set **AH1**<**AL1**. When the temperature decrease to **AH1**, the J1 relay will be closed (alarm on), when the temperature increases to **AL1**, the J1 relay will be open (alarm off).




Figure 6. High/Low alarm

10 Examples

10.1 Control a 110V Heater via SSR

Use SSR, thermocouple to work with the controller to hold the temperature at 700 °F. Please see [Figure 7](#) for wiring diagram.

Parameter setting: SV=700. Keep default settings for all the other parameters.




Figure 7. SSR Wiring Diagram

10.2 Control a 110V AC Solenoid Valve

Use PT100 probe to work with 110V AC solenoid valve. Please see [Figure 8](#) for wiring diagram.

- 1) To use PID mode to control the valve, set out=1, set cycle time ot=15 seconds to save the lifetime of the J1 relay and the valve. Set the SV to the desired temperature you want to hold, for example, SV=350°F.
- 2) To keep the temperature in a range, for example, 345-350°F, set the output control to on/off mode, out=4; keep the cycle time setting ot=2. Set SV=350, Hy=5. The output will be off when temperature goes above 350°F, and will be on again when temperature drops down to SV-Hy=345°F.

Note: For 220V AC solenoid valve, change the power source to 220V AC, use hot line 1 (L1) and hot line 2 (L2) to power the controller and the valve.




Figure 8. Solenoid Valve Wiring

10.3 Control a 220V AC Heater via Contactor

If heater draws more than 3A, the J1 relay could not handle it directly. A 220V coil contactor can be used to power the heater.




Figure 9. Use Contactor for Heater

- 1) To use PID mode to control the heater, set out=1, set cycle time ot=15 seconds to save the lifetime of the J1 relay and contactor. Set the SV to the desired temperature you want to hold, for example, SV=350°F.
- 2) To keep the temperature in a range, for example, 330-350°F, set the output control to on/off mode, out=4; keep the cycle time setting ot=2. Set SV=350, Hy=20. The output will be off when temperature goes above 350°F, and will be on again when temperature drops down to SV-Hy=320 °F.

10.4 Use J1 Relay to Trigger an 110V Alarm Buzzer

J1 relay is controlled by parameters AH1 and AL1 when J1 is set to alarm output (out=0, 2 or 3).

- 1) High alarm: If you want the buzzer to be on when temperature is higher than 210°F, and to be off when temperature drops down to 205°F, set AH1=210, AL1=205 (AH>AL).
- 2) Low alarm: If you want the buzzer to be on when temperature is lower than 5°F, and to be off when temperature goes back to 10°F, set AH1=5, AL1=10 (AH<AL).




Figure 10. Use J1 Relay for Alarm

11 Quick Guide

First, set the parameter **Int** to the sensor type connected to the controller if it is not a K type thermocouple, set the parameter **Out** for the output control mode. For controlling a mechanical relay in PID mode, change the cycle time **ot** to 5~60 seconds to save the lifetime of the relay. Then you are ready to go. For PID mode, if the system is not able to hold the temperature, run [Auto tune](#). Set the alarm parameters **AH**, **AL** if needed.

If the controller displays EEE, that means something wrong with the input or with the setting of the input. Please check the sensor connection and the **Int** parameter setting. Questions? Please contact us.

Golander LLC
<http://golanderusa.com>
 email: info@golanderusa.com